

SAMSUNG

3D Active Glasses

SSG-3300CR SSG-3300GR SSG-3700CR

User's Guide

Features


The 3D glasses enable you to view 3D images. To view 3D images, you need both a pair of 3D glasses and a Samsung 3D TV. The product allows you to connect devices via the 2.4GHz RF band.

- The Samsung 3D glasses cannot connect to a non-Samsung wireless communication device.
- 3D glasses can only connect to a Samsung 3D TV (D Series) released after 2011.

RX lens (prescription lenses) Ready option (SSG-3300CR / SSG-3700CR)

- This product is compatible with Rx (prescription) lenses in some regions. Visit www.samsung.com for details about Rx (prescription) lenses.

Parts




Components

- 3D Active Glasses
- User guide
- Cleaning cloth
- Micro USB Cable
- Nose support
- Shade

- For details on how to attach or detach the shade and nose support, refer to the last chapter in this manual.
- The appearance and color may vary depending on the model.
(The image provided herein represents the SSG-3300CR model.)

Performing 3D Active Glasses pairing

- What is Pairing?** Pairing is a process of connecting 3D glasses and a 3D TV and exchanging data between the two devices.




Pairing: The LED will blink green and red alternately for 2 seconds if pairing is in progress.

Powering on/off the 3D glasses: Putting on the 3D glasses automatically powers them on and turns on the green LED for 3 seconds. If the glasses are taken off, they will automatically power off shortly after and the red LED will be lit for 3 seconds.

Operating range

Recommended pairing distance



Recommended viewing distance	2~6m
Recommended pairing distance	50cm

- Ensure your Samsung TV and 3D glasses are no farther than 50 cm apart from each other while pairing is in progress.
- The working distance depends on obstacles (a person, metal, walls, etc.) or electromagnetic waves.
- Note that even if you take off the 3D glasses while viewing 3D video, with 3D mode enabled on the TV, it will take 5 minutes for the 3D glasses to power off.

◆ Pairing for the first time

1. Turn on the TV.
2. Press the pairing button on the 3D glasses shortly. The 3D glasses will power on and pairing will start.
3. The message “3D glasses are connected” will be displayed on the TV screen when the pairing is successfully completed.
4. Enjoy 3D video after configuring the 3D function settings on the TV.
 - ✎ After the first pairing, putting on the 3D glasses will automatically power on the glasses. To power off, take off the glasses.
 - ✎ If the pairing failed, the 3D glasses will power off.
 - ✎ If the first attempt to pair fails, power the monitor off and on again and perform step 2.


◆ **How to pair again:** Press the pairing button on the 3D glasses for more than 2 seconds.

<Pairing is needed again in the following occasions>

- Pairing may be needed again after the 3D TV is repaired.
- You want to view a 3D video on a new Samsung 3D TV released in 2011.

◆ Charging the Battery

If the red LED blinks every 2 seconds, charge the battery as shown below. The orange LED will blink every second when battery charging is in progress. The green LED will blink every 2 seconds when the charging is finished.



✎ A wireless battery charger can be purchased in some regions. For details on the wireless battery charger, visit www.samsung.com.

◆ Viewing guidelines

- When viewing 3D video under a fluorescent lamp (50Hz – 60Hz) or 3-wavelength lamp, you may notice a small amount of screen flickering.
 - ※ If so, dim the light or turn the lamp off.
- Switching the input mode while watching a 3D movie may disable the 3D function on the TV. As a result, the 3D glasses may not function and the movie may not be displayed properly.
- If the 3D glasses move outside of the recommended operating distance, the signal from the TV will be disconnected and the display of the 3D glasses will turn off after several seconds. The 3D glasses will automatically power off about 3 minutes after the display turns off. When this happens, the red LED will turn on for 3 seconds.
 - ※ Under some circumstances, the 3D glasses may malfunction due to interference from other devices.

- The vividness of the image may appear degraded if you view 3D video in a place that is exposed to direct sunlight or illumination.
- Ensure you are within the working distance when you view a 3D video.
 - ※ The images may not be viewable in 3D if you move outside of the working distance for 3 seconds.
- If you lie on your side while watching TV with 3D glasses, the picture may look dark or may not be visible.
- The 3D effect may be experienced differently depending on the viewer. You may not notice the 3D effect at all if you have a prescription for one eye that is very different from the other eye.
- If a lens or any part of the 3D glasses is defective or damaged, the glasses cannot be repaired and should be exchanged. Broken 3D glasses can be exchanged for a new pair free of charge within the warranty period. Note that damage caused by the fault of the user is not covered by the warranty.
- The 3D glasses may not function properly if there are any nearby 3D products or electromagnetic devices (a microwave or a device that uses 2.4 GHz-bandwidth frequency such as an Internet router) turned on. If an unintended operation of the 3D function occurs, it is best to remove nearby electromagnetic devices or wireless communications devices.
- The 3D glasses may malfunction if there is any electric field or metallic object such as a steel plate nearby. If an unintended operation of the 3D glasses occurs, it is best to keep the glasses as far away as possible from the metallic object.
- If you do not wear the 3D glasses properly, the glasses may power off while operating. To resolve this issue, wear the glasses properly.
- The glasses may power off if you remain stationary while viewing 3D video for an extended period of time.

CAUTION

IMPORTANT HEALTH AND SAFETY INFORMATION FOR 3D IMAGES. READ THE FOLLOWING CAUTIONS BEFORE YOU OR YOUR CHILD USE THE 3D FUNCTION.

- A responsible adult should frequently check on children who are using the 3D function. If your child shows any symptom such as eye fatigue, headache, dizziness, or nausea, stop the child from watching 3D video immediately to rest.
- Do not use the 3D glasses for other purposes such as general eyeglasses, sunglasses, protective goggles, etc.
- While watching 3D content, you may experience eye strain, headache, dizziness and nausea. If eye fatigue occurs, stop viewing 3D video immediately, take off the 3D glasses, and rest.
- Viewing 3D video for an extended period of time may cause eye fatigue. If eye fatigue occurs, stop viewing 3D video immediately, take off the 3D glasses, and rest.
- Do not use the 3D function or 3D glasses while walking or moving around. Using the 3D function or 3D Active Glasses while moving around may result in injury from running into objects, tripping, and/or falling.
- If you sleep with the 3D glasses on, the temples on the glasses may become broken.

SAFETY PRECAUTIONS

The following safety instructions are to ensure your personal safety and prevent property damage. Please read the following to ensure the proper use of the product.

- Do not place the TV camera in an area exposed to direct sunlight, heat or humidity or else breakdown or fire may result.
- Do not apply force to the lenses of the 3D glasses. Do not drop or bend the product. This may result in a product malfunction.
- Keep components of the 3D glasses out of reach of children, and especially ensure children do not swallow one of the components. If your child swallowed a component, consult your doctor immediately.


- Do not spray water or cleaning agent directly on the camera or else fire, electric shock, damage to the exterior, or removal of the labels may result.
- Do not apply chemicals (wax, benzene, thinner, mosquito repellent, air freshener, lubricant, or cleaning agent) or products that contain alcohol, solvent or surfactant to the camera.
- Since the product surface and lens are easily scratched, make sure to use a clean soft cloth (the cleaning cloth supplied with the product, a cloth consisting of superfine fibers or cotton flannel) when cleaning to avoid scratching either the surface or the lens. As the product may become scratched if there are any foreign items on the cloth, make sure to shake off any dust before using it.
- Do not disassemble, or attempt to repair or modify your 3D active glasses by yourself.
- Be careful not to let the temple ends of the 3D active glasses harm your eye.
- Do not sleep with the 3D glasses on. The arms on the glasses may become broken.
- Make sure to use only 3D glasses that are authorized and supplied by Samsung Electronics.

Troubleshooting

If you encounter...	Try this...
My 3D glasses do not work.	<ul style="list-style-type: none"> ➤ The 3D glasses should be close to the TV. Make sure that the distance between the TV and your 3D glasses is less than 19.68 feet (6m) in a straight line. ➤ Press the pairing button for more than 2 seconds to check that the pairing is complete. ➤ Check the 3D function settings on the TV. ➤ Take off the glasses and put them on again. The glasses may turn off if not put on properly.
My 3D glasses do not work.	<ul style="list-style-type: none"> ➤ The battery is low. Charge the battery.

Specifications (Model Number: SSG-3300CR SSG-3300GR SSG-3700CR)

Optics	Shutters	Liquid crystal	Transmittance	37±2%
	Recommended viewing distance	2~6m	Field Rate	120 fields/s
Weight	SSG-3300CR SSG-3300GR SSG-3700CR	33.5g(SSG-3300CR) 39.0g(SSG-3300GR) 28.5g(SSG-3700CR)		
Power	Glasses	3.7 V Lithum Polymer battery 1 EA		
Power Consumption	Glasses	1.6mA(SSG-3300CR), 1.3mA(SSG-3300GR/SSG-3700CR)		
	Battery	Type	70mA, 3.7V	
		Operating time when On	40Hr	
Operating Conditions	Operating Temperature	32°F to 104°F (0°C to 40°C)		
	Custody Temperature	-4°F to 140°F (-20°C to 60°C)		

 Product specifications may be changed without notice in order to enhance product performance.

WARRANTY

This Samsung product is warranted for the period of twelve (12) months from the original date of purchase, against defective materials and workmanship. In the event that warranty service is required, you should first return the product to the retailer from whom it was purchased. However, Samsung Authorized Service Centres will comply with this warranty during the Warranty Period. To obtain details, please contact your nearest Authorized Service Centre.

PROCEDURE FOR MAKING A WARRANTY CLAIM

To make a claim under the warranty, you must contact the Samsung Contact Centre (see details above) during the Warranty Period to discuss the problems you are having with the product. If a repair or replacement is required, you will be provided with a Warranty Claim Number and address of an Authorised Service Centre.

If you are provided with a Warranty Claim Number, to obtain a repair or replacement of the product, you must send the product to the Authorised Service Centre advised together with:

- a copy of your completed warranty card or, if you have already provided this to Samsung, your name, address and contact telephone number;
- your original receipt, invoice or sales slip for the purchase of the product as new;
- your Warranty Claim Number.

Samsung will then repair or replace the product and return it to you using the contact details provided.

WARRANTY CONDITIONS

1. The warranty is only valid if the above procedure for making a warranty claim is followed.
2. Samsung's obligations are limited to the repair or, at its discretion, replacement of the product or the defective part.
3. Warranty repairs must be carried out by Samsung Authorised Service Centres. No reimbursement will be made for repairs carried out by service centres or dealers that are not authorised by Samsung and any such repair work and damage to the products caused by such repair work will not be covered by this warranty.
4. This product is not considered to be defective in materials nor workmanship by reason that it requires adaptation in order to conform to national or local technical or safety standards in force in any country other than the one for which the product was originally designed and manufactured. This warranty will not cover, and no re-imbursement will be made for such adaptation, nor any damage which may result.


5. The warranty does not apply to any product that has been damaged or rendered defective as a result of any of the following excluded reasons, namely:

- as a result of accident, misuse, or abuse;
- through the failure to use this product for its normal purposes;
- by the use of parts not manufactured or sold by Samsung;
- by modification without the written permission of Samsung;
- by damage resulting from transit, neglect, power surge or failure;
- by damage resulting from lightning, water, fire, or acts of God;
- as a result of normal wear and tear; or
- difference in broadcasting methods or product standards between countries.


6. This warranty is valid for any person who legally acquired possession of the product during the warranty period.
7. NOTHING IN THESE WARRANTY CONDITIONS SHALL EXCLUDE OR LIMIT SAMSUNG'S LIABILITY FOR DEATH OR PERSONAL INJURY CAUSED BY THE PROVEN NEGLIGENCE OF SAMSUNG, UNLESS SUCH LIMITATION OR EXCLUSION IS PERMITTED BY APPLICABLE LAW.
8. WITH THE EXCEPTION OF SAMSUNG'S LIABILITY WHICH CANNOT BE EXCLUDED OR LIMITED BY LAW, SAMSUNG SHALL NOT BE LIABLE FOR: ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES LOSSES OR EXPENSES; OR LOST PROFITS; OR LOSS OF USE OR LOSS OF DATA; OR DAMAGE TO GOODWILL, REPUTATION OR LOST BUSINESS, ARISING DIRECTLY OR INDIRECTLY, FROM THE PURCHASE, USE OR SALE OF THE PRODUCT, WHETHER OR NOT SAMSUNG WAS ADVISED OR AWARE OF THE POSSIBILITY OF SUCH DAMAGES, LOSSES OR EXPENSES.
9. WITH THE EXCEPTION OF SAMSUNG'S LIABILITY WHICH CANNOT BE EXCLUDED OR LIMITED BY LAW, SAMSUNG'S LIABILITY UNDER OR IN CONNECTION WITH THIS WARRANTY OR THE PURCHASE, USE OR SALE OF THE PRODUCT SHALL NOT EXCEED THE PRICE PAID FOR THE PRODUCT AS NEW.
10. UNLESS PROVIDED FOR IN THIS WARRANTY, ALL CONDITIONS, WARRANTIES AND TERMS IMPLIED BY STATUTE OR OTHERWISE ARE HEREBY EXCLUDED TO THE MAXIMUM EXTENT PERMISSIBLE BY LAW.
11. The above warranty conditions do not affect your statutory rights as a consumer or otherwise.

◆ **SSG-3700CR**


- Attaching the shade



- Detaching the nose support




- Attaching the nose support




◆ **SSG-3300CR / SSG-3300GR**


- Attaching the shade



- Detaching the nose support




- Attaching the nose support





◆ **SSG-3700CR**



- Attaching the shade



- Detaching the nose support




- Attaching the nose support





◆ **SSG-3300CR / SSG-3300GR**



- Attaching the shade



- Detaching the nose support



- Attaching the nose support



Notice

◆ FCC Statement

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

◆ IC Statement

This Class B digital apparatus complies with Canadian ICES-003.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Regulatory Compliance Statements

FCC COMPLIANCE

1) Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

2) NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

If an apparatus is provided with a replaceable lithium battery, the following applies:

- if the battery is intended to be replaced by the USER, there shall be a warning close to the battery or in both the instructions for use and the service instructions;
- if the battery is not intended to be replaced by the USER, there shall be a warning close to the battery or in the service instructions.

CAUTION

Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type.

A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

ICES-003 Class B Notice - Avis NMB-003, Classe B

This Class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Italian Homologation Notice

Questo apparecchio e fabbricato in conformita al D.M.28.08.95 n.548 ed in particolare a quanto specificato nell Art.2, comma 1.
Questo apparecchio e fabbricato nella U.E. in conformita al D.M.28.08.95 n.548 Art.2, comma 1 ed al D.M.26.03.92 Art.1

- For products produced in countries except European Community Questo

apparecchio e fabbricato in conformita al D.M.28.08.95 n.548 ed in particolare a quanto specificato nell Art.2, comma 1.
- For products produced in European Community Questo apparecchio e fabbricato nella U.E. in conformita al D.M.28.08.95 n.548 Art.2, comma 1 ed al D.M.26.03.92 Art.1



Contact SAMSUNG WORLD WIDE

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care center.

Region	Contact Center ☎	Web Site
North America	CANADA 1-800-SAMSUNG(726-7864)	www.samsung.com
	MEXICO 01-800-SAMSUNG(726-7864)	www.samsung.com
	U.S.A 1-800-SAMSUNG(726-7864)	www.samsung.com
	ARGENTINE 0800-333-3733	www.samsung.com
Latin America	BRAZIL 0800-124-421, 4004-0000	www.samsung.com
	CHILE 800-SAMSUNG(726-7864)	www.samsung.com
	NICARAGUA 00-1800-5077267	www.samsung.com
	HONDURAS 800-7919267	www.samsung.com
	COSTA RICA 0-800-507-7267	www.samsung.com
	ECUADOR 1-800-10-7267	www.samsung.com
	EL SALVADOR 800-6225	www.samsung.com
	GUATEMALA 1-800-299-0013	www.samsung.com
	JAMAICA 1-800-234-7267	www.samsung.com
	PANAMA 800-7267	www.samsung.com
	PUERTO RICO 1-800-682-3180	www.samsung.com
	REP. DOMINICA 1-800-751-2676	www.samsung.com
	TRINIDAD & TOBAGO 1-800-SAMSUNG(726-7864)	www.samsung.com
	VENEZUELA 0-800-100-5303	www.samsung.com
	COLOMBIA 01-8000112112	www.samsung.com
CIS	RUSSIA 8-800-555-55-55	www.samsung.com
	GEORGIA 8-800-555-555	-
	ARMENIA 0-800-05-555	-
	AZERBAIJAN 088-55-55-555	-
	KAZAKHSTAN 8-10-800-500-55-500	-
	UZBEKISTAN 8-10-800-500-55-500	www.samsung.com
	KYRGYZSTAN 00-800-500-55-500	www.samsung.com
	TADJIKISTAN 8-10-800-500-55-500	www.samsung.com
	UKRAINE 0-800-502-000	www.samsung.ua www.samsung.com/ua_ru
	BELARUS 810-800-500-55-500	-
	MOLDOVA 00-800-500-55-500	-

Region	Contact Center ☎	Web Site
Asia Pacific	AUSTRALIA 1300 362 603	www.samsung.com
	CHINA 400-810-5858, 010-6475 1880	www.samsung.com
	HONG KONG (852) 3698-4698	www.samsung.com/hk www.samsung.com/hk_en/
	INDIA 3030 8282, 1800 110011 1800 3000 8282, 1800 266 8282	www.samsung.com
	INDONESIA 0800-112-8888, 021-5699-7777	www.samsung.com
	JAPAN 0120-327-527	www.samsung.com
	Republic of Korea 1588-3366	www.samsung.com/sec
	MALAYSIA 1800-88-9999	www.samsung.com
	NEW ZEALAND 0800 SAMSUNG (0800 726 786)	www.samsung.com
	PHILIPPINES 1-800-10-SAMSUNG(726-7864) 1-800-3-SAMSUNG(726-7864) 1-800-8-SAMSUNG(726-7864) 02-5805777	www.samsung.com
	Republic of Korea 1588-3366	www.samsung.com/sec
	TAIWAN 0800-329-999	www.samsung.com
	THAILAND 1800-29-3232, 02-689-3232	www.samsung.com
	VIETNAM 1 800 588 889	www.samsung.com
Middle East & Africa	BAHRAIN 8000-4726	-
	JORDAN 800-22273	-
	SOUTH AFRICA 0860-SAMSUNG(726-7864)	www.samsung.com
	TURKEY 444 77 11	www.samsung.com
	U.A.E 800-SAMSUNG (726-7864)	www.samsung.com